

o'clock. It just sits there stopped to let you know there has been a power failure. Setting the time will start it running.

Stopping the Color Changing

There is a light sensor/switch that you can use to stop the color changing on your favorite colors. You might want Red-Green for Christmas or Blue-Green to go with your decor. The sensor is pointed downward and located as shown in picture. Just like when you set the time, you must hold the flash light below the target and shine it upward. If the lights blink you have done it. (Note: The Hour-Pattern Switching Turn OFF switch is nearby. If you activate it in error, the hour pattern will not switch for artistic balance. The quantity of dots still shifts.)

Accuracy

The clock is accurate within 2 seconds except if there is a power interruption. During a power interruption the clock would gain or lose 1 second/minute of no-power.

Trouble? Using the Reset Switch

If the clock face goes blank (no light on) or fails to work properly, do the following:

Unplug the clock from the wall.

Remove one of the batteries from the back.

Hold down the reset switch on the back for 20 seconds.

Then plug the clock back in. The one o'clock light should come on.

Then, finally, put the batteries back in and reset the time.

Problems, Solutions, The Shipping Box

Keep the Shipping box and packing material for at least the first 90 days. Most failures happen soon and this will make your life easier if there is a problem.

If the clock is changing time and there has been no power failures, try setting the clock

and then turning it towards the wall for a day. If it now keeps time then some light must be shining on the clock during the day. Usually it's the sun coming in a window and reflecting off a smooth surface. If you have this problem and can't find a good solution, let me know.

Send in the Registration Card

If I move I need to keep you informed. Or if I have updates to offer, I'll need your address.

Warranty & Repair

Your clock is guaranteed against defects, under normal use, for one year from the day of purchase. The warranty covers parts and labor only. All repairs are done at the factory. If you have any difficulty with the clock please write or call the factory.

A Personal Note

My name is Barry Gamble. I have been designing art clocks for 32 years. I love the creation process. My design goals are to delight, charm, and be fun. The product should be chic, sophisticated, make-a-statement, and make an adult giggle.

The clocks are not sold in stores so it's exposure is limited. I doubt that I will sell more than 50 of ChronoArt II. Each one is numbered starting at 1. Each one is signed on the back.

I do my best to deliver a quality product, deliver promptly, and charge only a reasonable profit.

To make sure this art piece can run long after both you and I are gone, you should find an Electronic Schematic, Bill of Materials, and a Trouble Shooting Guide for your neighborhood electronic tech. You might want to store these on the back of the clock.

Enjoy!

ChronoArt Inc.
9175 Poplar Ave.
Cotati, CA 94931
707-795-1895